



US006055889A

United States Patent [19]
Rinner

[11] **Patent Number:** **6,055,889**
[45] **Date of Patent:** **May 2, 2000**

- [54] **HAND MANIPULATED TORQUE TRANSMITTING TOOL**
- [75] Inventor: **James A. Rinner**, Racine, Wis.
- [73] Assignee: **Beere Precision Medical Instruments, Inc.**, Racine, Wis.
- [21] Appl. No.: **09/228,130**
- [22] Filed: **Jan. 11, 1999**
- [51] **Int. Cl.⁷** **B25B 23/16**
- [52] **U.S. Cl.** **81/177.85; 81/489**
- [58] **Field of Search** **81/177.1, 177.85, 81/489**

4,779,493	10/1988	White	81/438
4,905,549	3/1990	Nickipuck	81/177.85
5,289,745	3/1994	Beardsley	81/177.2
5,442,980	8/1995	Ringer	81/177.85
5,685,208	11/1997	Tidwell	81/177.85
5,720,207	2/1998	Milner et al.	81/177.85

Primary Examiner—James G. Smith
Assistant Examiner—David B. Thomas
Attorney, Agent, or Firm—Arthur J. Hansmann

[57] **ABSTRACT**

A hand manipulated torque transmitting tool having a handle and two tool shank-receiving cavities therein. A shank retainer ball extends into each cavity, and the shank has a circular groove therearound for receiving said ball when in either cavity. The shank has a square drive end mating with a square hollow of said cavities, for four-corner drive from said handle to said shank.

- [56] **References Cited**
U.S. PATENT DOCUMENTS
D. 148,621 2/1948 Herman 81/177.1

12 Claims, 3 Drawing Sheets

