



US006807883B1

(12) **United States Patent**  
**Rinner**

(10) **Patent No.:** **US 6,807,883 B1**

(45) **Date of Patent:** **Oct. 26, 2004**

(54) **TORQUE TOOL HANDLE FOR  
RELEASABLE SHANK**

(75) **Inventor:** **James A. Rinner, Racine, WI (US)**

(73) **Assignee:** **Pilling Weck Incorporated, Horsham,  
PA (US)**

(\*) **Notice:** Subject to any disclaimer, the term of this patent is extended or adjusted under 35 U.S.C. 154(b) by 119 days.

3,955,451 A *	5/1976	Lohness	81/177.1
4,692,073 A *	9/1987	Martindell	81/438
4,905,549 A	3/1990	Nickipuck	
5,533,429 A *	7/1996	Kozak	81/438
5,685,208 A	11/1997	Tidwell	
6,055,889 A	5/2000	Rinner	
6,199,872 B1 *	3/2001	Hasan	81/438
6,363,819 B1 *	4/2002	Li	81/438
6,564,680 B1 *	5/2003	Rinner et al.	81/177.5

\* cited by examiner

*Primary Examiner*—James G. Smith

(74) *Attorney, Agent, or Firm*—Arthur J. Hansmann

(21) **Appl. No.:** **10/215,405**

(22) **Filed:** **Aug. 9, 2002**

(51) **Int. Cl.**<sup>7</sup> ..... **B25B 23/16**

(52) **U.S. Cl.** ..... **81/177.5; 81/489**

(58) **Field of Search** ..... 81/177.1, 177.5,  
81/177.85, 438, 489

(57) **ABSTRACT**

A torque tool handle for releasably holding a driven shank, such as a screwdriver bit. The handle is elongated and has an opening with a sleeve therein carrying a detent and an actuator which is slidable on the sleeve for alternate locking and release of the detent relative to the shank disposed in the sleeve. There can be two handle openings at right angles to each other and with each having a sleeve and an actuator and a detent, so the handle is both an axial and a T-handle driver.

(56) **References Cited**

U.S. PATENT DOCUMENTS

1,578,065 A *	3/1926	Bemus et al.	81/177.5
D148,621 S	2/1948	Herman	D54/16

**6 Claims, 3 Drawing Sheets**

